

**GENERAL
WARNING**

FATO is floating. Do not land there. Use TLOF on landside as heliport.

Operational hours

AD OPS Hours H24, PPR 15 min

Airport information

Note. AIP ESSB: Outside ATS hours of operation should be transmitted on freq. 118:105 when flying over Stockholm and Stockholm city.

Ambulance and rescuer flights only

PPR 15 min H24 Rescue Coordination Center (SOSAB) PN H24 +46 8 454 23 62.

Clear to land when lights are on or radio contact.

Airport lightning can be lit up by Rakel Status 39135 MSISDN and extinguish Status: 39136 MSISDN or lit up by sending on freq. 122.875, 1 long- 7 sec, + 4 short within 1,8 sec.

Emergency reception + 46 8 123 55 671

Switchboard +46 8-123 55 000

Communication

Rakel 330-3432

Clearance

Clearance from ESSB TWR when opening.

Heliport information

Heliport information							
ESHD							
	POS TLOF LAT 59 23,27N/ LONG 018 0200, E(*)						
	POS FATO LAT 59 23.30N / LONG 018 01,45 E(*)						
Proportion/dimension for HKP EC/H 145 D value max 13,63 m MLW 6 ton	AD TLOF ELEV 5 ft./ FATO ELEV 2 ft. TLOF Ø 20 m Surface Asphalt FATO 19m x19 m Surface wood floating/moored						
	SECTORS						
	<table border="1" style="width: 100%;"> <thead> <tr> <th style="text-align: left;">APPROACH</th> <th style="text-align: left;">DEPARTURE</th> </tr> </thead> <tbody> <tr> <td>W (west) 4,5% 093°TH</td> <td>4,5 % 273°TH</td> </tr> <tr> <td>S (South) 8% 347° TH</td> <td>8 %% 167° TH</td> </tr> </tbody> </table>	APPROACH	DEPARTURE	W (west) 4,5% 093°TH	4,5 % 273°TH	S (South) 8% 347° TH	8 %% 167° TH
APPROACH	DEPARTURE						
W (west) 4,5% 093°TH	4,5 % 273°TH						
S (South) 8% 347° TH	8 %% 167° TH						
RFF 2 hose spray 4 Fire Extinguisher 12 kg	Lights: TLOF 16 green perimeter + 2 floodlights FATO 12 white perimeter Lightning Windsock						

